

mPRIME short instructions



Accepting payments

1. Enter the purchase amount in the app.
If desired, create a purchase reference underneath the amount (e.g. product name).
 2. Select <Checkout>.
 3. Hand the card reader to the customer.
 4. Customer inserts their card, enters their PIN and confirms again with the <O> button.
For some cards, a signature is required instead of a PIN. Have the customer sign by hand on the touchscreen of the smartphone/tablet.
- 4.1 Contactless payment**
- On the mPRIME device, the contactless function is always switched on. As soon as the amount appears on the terminal, the card holder can hold their card over the display or near the four LED lights. If the payment was successful, the four LEDs light up. You can tell if the card is contactless with this symbol:)))
5. The payment is verified and processed. This may take a few seconds.
 6. The customer takes their card back.
 7. Would you like to send our customer a purchase receipt by email?
 1. Press <Send email>.
 2. Select email client you have already installed.
 3. Enter your customer's email address.
 4. Send the email.

Cancelling payments

You can cancel the last payment in the app:

1. In the app, select the menu list on the upper left-hand side.
2. Select the <History> function under Administration.
3. Select the last transaction that was carried out from the list.
Select <Refund money>. Would you like to cancel another payment? Write an email to the responsible customer services. You can find the details at: www.mprime.me

Crediting payments

You can issue a credit note at any time in the app:

1. In the app, select the menu list on the upper left-hand side.
2. Select the <New credit> function in the app.
3. Confirm your selection.
4. Enter the amount in the app and then press <Checkout>.
5. Hand the card reader to your customer.
6. Customer inserts their payment card and confirms the amount.

Daily closing

With daily closing, all transactions that have been carried out are sent to the card processors and completed. By carrying out daily closing, the amounts are credited to your bank account. Daily closing should be done at least once a day, preferably after closing time.

1. In the app, select the menu list on the upper left-hand side.
2. Select the <Balance> function under Administration.
3. Confirm your selection.

Switching mPRIME card reader on/off

The card reader automatically switches to standby mode after 2 minutes. Press any button to end standby mode. The card reader can be switched off by holding down the <X> key and switched on by holding down the <O> key.

Changing the card reader

If you want to connect an additional or new card reader to your device, select the "card reader" menu item in the SIX mPRIME app to add an additional device.

Requirements for tablet/smartphone

- Active SIM card with data bundle
- Android: minimum version 6
- iOS: minimum version 10

Charging the battery

The card reader is fitted with a powerful battery. The battery can be charged via USB.

Battery status display:

- 20%–16%: "Battery almost empty!" For every transaction, the following notice is displayed briefly: "Please connect to power supply".
- 15%–10%: "Battery empty!" Transactions are denied with the warning "Please connect to power supply".
- < 10%: "Battery empty!" The Bluetooth connection is disconnected!

Hotline

Phone: +352 49 10 38

E-mail: luxterminalsupport@six-payment-services.com

Service operated: Monday - Friday, 8 a.m. - 6 p.m.

Your local point of contact can be found at: www.six-payment-services.com/contact

SIX Payment Services Ltd
Hardturmstrasse 201
8021 Zurich
Switzerland

SIX Payment Services (Europe) S.A.
Austrian branch
Marxergasse 1B
A-1030 Vienna

SIX Payment Services (Europe) S.A.
10, rue Gabriel Lippmann
5365 Munsbach
Luxembourg

SIX Payment Services (Europe) S.A.
German branch
Franklinstrasse 61-63
D-60486 Frankfurt/Main

